







somfy.com

# RS485 RTS transmitter



Picture  
no contractual


With the new Somfy RTS motor controller, you can manage all your Somfy applications easily using the same centralized home control system.



# RS485 RTS TRANSMITTER

## Functions


- Control the whole range of Somfy RTS products




Roman & pleated shades




Curtains




Venetian blinds



Roller shades



Awnings



Roller shutters


- Control up to 16 groups of products
- Can be controlled via:
  - RS485 <sup>(1)</sup> - Dry contact / relays

<sup>(1)</sup>The interface has its own network @

## Technical specifications

<b>Supply (Nominal / Frequency)</b>	From 90V to 255V AC - 50/60 Hz
<b>Amps</b>	100 mA at 90V
	50 mA at 255V
<b>RTS transmitter</b>	433 MHz
	200m free field
	20m between 2 concrete walls
<b>Connectors</b>	RS485: 4 pin
	Dry contact: up to 5 3-pin 3.5mm detachable terminal blocks
	External antenna
<b>Temperature</b>	From 0°C to 60°C
<b>IP20</b>	
<b>CE</b>	

## Wiring



Picture  
no contractual